

Instructions

These instructions apply to fitting the Notebook PC Shelf to Aero series, Model L2001 and L2001C, only.


A different fitting system applies to all other models.

The brackets attach to the channel on the top cross bar at the back of your Lectrum.

Please note, the two top bolts are fixed and cannot be tightened or loosened. The two bottom bolts are free and should be adjusted to make sure that the Notebook PC Shelf is firmly fixed in position.

1. Fully loosen the two bottom bolts but do not remove.
2. From behind your Lectrum with the shelf on the right hand side, position the top bolts in the top channel of the top cross bar and pull (snap) down into position.
3. Once the Notebook PC Shelf is in the correct position, tighten the bottom bolts into the bottom channel for a secure fit.
4. Check for ease of operation. the slide out operation of the Notebook PC Shelf may be slightly tight when first used. This is normal.

Your Aero Notebook PC Shelf is supplied complete and ready to install with the hex key provided.



Manufactured & Distributed By:

WILSON GILKES
MANUFACTURING IDEAS

P.O. Box 63
Moorebank NSW 1875
337 - 349 Newbridge Road
Moorebank NSW 2170

Telephone: (02) 9914 0900
Fax: (02) 9914 0901
Email: sales@gilkon.com.au

www.lectrum.com.au